


No. 423BP

To Replace Seat Disc

1. Shut off water supply to toilet.
Flush toilet to empty tank.
2. Unscrew worn seat disc from post.
3. Screw on new seat disc.
4. Turn on water supply.



UPC:

049057042397