


## Part No. 43BP

### Instructions:

1. Loosen ring from flapper with pliers.
2. Remove worn chain and replace with new chain.
3. Attach hook to end of chain, then to flush valve.



**UPC:**

**049057004395**